

918DP Alarm Hand Tool

Installation Instructions

Alarm hand tool is provided for assistance in setting alarm points for the 918DP clock gauge. Slide tool under desired alarm hand and align slot in tool with the hand on the gauge. Pull up and rotate to the desired setting and then allow hand to seat back in. Remove alarm hand tool.



Figure 1