

# Aboveground Storage Tank - Bulk Storage

Fig. 922 Combination Vent/Overfill Alarm or Pressure Vacuum Vent or Vacuum Vent

Fig. 2440 Series Emergency Vents

Fig. 1218S Tank Level Sensor




Fig. 272DI Internal Emergency Valve

Fig. 534BDI Gate Valve with Expansion Relief

Fig. 272DI Internal Emergency Valve

Fig. 534BDI Gate Valve with Expansion Relief

Fig. 246DRF Swing Check Valve

Fig. 285FDI Bottom Clean-Out Line Strainer

Fig. 515/SD or 715 (w/ SS components) or 715S Remote Spill Container

