


## EVR Approved Direct Fill Male Threaded Tank Connection



The Drop Tube Diffuser and Overfill Prevention device may have to be removed (if installed) upon District request to verify the existence of a submerged fill pipe.